



PERSONAL HERBAL INHALER

Contents

- (1) DaVinci MIQRO C
- (1) 18350 mAh Battery
- (1) Mouthpiece (Silicone)
- (1) 10MM Water Tool Adapter (Silicone)
- (1) Pearl Post
- (1) Pearl Gasket
- (1) 3-Ft Braided Nylon Type C Charging Cable
- (1) Extra Pick Tool
- (3) Alcohol Cleaning Wipes
- (2) DaVinci Stickers
- (1) Owners Manual
- (1) Customer Support & Registration Card



How To Use

- 1) Open the MIQRO C's bottom lid to reveal the glass-lined ceramic oven.
- 2) Pack tightly for maximum vapor.
- 3) Close the bottom lid to allow the pearl to firmly pack the herb.
- 4) Power on the device by clicking the Control Button 5x within 3 seconds.
- 5) Allow 39 seconds for maximum heat-up and voilà enjoy the DaVinci MIQRO C experience.



POWER
(black)



GROWTH
(dark green)



JOY
(magenta)



CLARITY
(yellow)

FAQ

General Information

- **What are the unique features of the DaVinci MIQRO C?**

The DaVinci MIQRO C boasts superior flavor while being feature packed. Taste terpenes like you never have before. This tiny vaporizer has it all: highlighting Clean First Technology, Smart Path temperature control, replaceable battery, and USB Type C charging. DaVinci promises to build with only the cleanest componentry and a Clean First Technology ethos. No metals or plastics are used in our sealed zirconia/glass airpath providing purity to the connoisseur. DaVinci's products are safety certified giving you peace of mind and exceptional flavor with every draw. We've used an FDA-approved microbial polymer blend on the mouthpiece to provide a more sanitary experience that will also feel cooler on your lips. DaVinci's alumina ceramic, glass-lined oven boasts a temperature control system with +/- 1° temperature accuracy. Use Smart Path Mode for an easy-to-use experience. With a replaceable and rechargeable 18350 battery, the MIQRO C offers up to a 30-minute run time. It can easily replace a drained battery with a new or degrading one. We've upgraded the MIQRO C with Type-C charging for prompt charging in 90-minutes. With all the included features and a 5-year warranty, you'll be getting the most innovative and cleanest tech available for years to come.

- **What is the upgrade program for the MIQRO C?**

The upgrade program is 20% off the MIQRO C with the exchange of your old MIQRO. You must contact our Customer Support team to start the process.

- **Is the MIQRO C the same size as the MQRO?**

Yes, the MIQRO C remains to be the world's smallest loose-leaf vaporizer built with Clean First® Technology. MIQRO C's exact dimensions are 23 x 34 x 80mm / 0.91 x 1.34 x 3.13 in.

- **How do I reset to factory default settings?**

While the device is turned off, press and hold the Control Button for 10 seconds.

- **Where can I find the MIQRO C's serial number?**

Your serial number can be found in the following places:

- 1) Engraved underneath the "MIQRO C" logo on the back of the device.
- 2) Printed on a transparent sticker typically located next to the UPC & barcode on the outer sleeve of the packaging.

- **Where is the MIQRO C manufactured?**

The MIQRO C is designed in the United States and manufactured in our China facility.

FAQ

General Information (Continued)

- **Can I vaporize essential oils in my MIQRO C?**

No, the MIQRO C is not intended to vaporize essential oils.

- **Does the MIQRO C display hidden words like the MIQRO?**

No, because of the newly added 4 light feature on the MIQRO C the device is unable to display any hidden words.

- **Does the MIQRO C connect to water pipes?**

The MIQRO C comes fitted with a flat mouthpiece for discreet, hygienic use. For use with water filtration systems, remove the flat mouthpiece and replace it with the 10mm Water Tool Adapter (silicone).

First, open the top cap of the MIQRO C and remove the flat mouthpiece. Replace it with the 10MM Water Tool Adapter inside of your top cap. Once you have installed your adapter, close the top cap, insert the 10mm adapter into your favorite water tool, and enjoy it!

- **Are the MIQRO accessories compatible with the MIQRO C?**

	 MIQRO C	 MIQRO
 MIQRO Glove		
 MIQRO Pick Tool Pack		
 Dual Use Carry Can		
 Small Soft Case		
 MIQRO 10mm Water Tool Adapter (Zirconia)		
 MIQRO Zirconia Vapor Path		
 MIQRO Mouthpiece (Zirconia)		

FAQ

Smart Paths™ Heat-up Times & Temperatures

- **What are the minimum & maximum temperatures of the MIQRO C?**

Minimum Temperature: 350°F / 176°C

Maximum Temperature: 430°F / 210°C

- **What is the full heat-up time for the MIQRO C?**

The MIQRO C has a 39-second heat-up time. Heat-up time will vary depending on the desired Smart Path mode.

- **Can I change my MIQRO C to read in Celsius?**

No, the MIQRO C does not display temperatures in Fahrenheit or Celsius.

- **How do I know which Smart Path™ is right for me?**

- Smart Path 1 – FLAVOR**

Use Smart Path 1 to spark creativity and enjoy the flavors of your herb. This temperature range is the perfect starting point for users who are new to the DaVinci experience and prefer the journey.

- Smart Path 2 – MIND**

Elevate into Smart Path 2 to stay awake and active, while gently enlightening your spirit. This temperature range is ideal for the casual user who is ready to socialize and have a good time.

- Smart Path 3 – BODY**

Explore Smart Path 3 to engulf yourself in a full-body sensation. This temperature range is optimal for a more frequent user who is ready to relax the body and free their mind.

- Smart Path 4 – REST**

Discover Smart Path 4 to release any stress or pain and allow intense sedation to captivate you. This temperature range is the ultimate choice for the expert user.

- **How do I control the MIQRO C temperature using Smart Paths™?**

Smart Paths are preset temperature experiences that will gradually increase the temperature over a 5-minute session.

Cycle through Smart Paths by pressing the Control Button 3 times. Settings will cycle back if increased past 4. The Smart Paths activate a temperature range that is traveled slowly over a path throughout your session delicately warming the spectrum of your dry herbs. See the photo to the right for the Smart Path temperature ranges.

SMART PATH™ MODE



Start temp 410°F / 210°C
End temp 430° / 221°C



Start temp 390°F / 199°C
End temp 410° / 210°C



Start temp 370°F / 188°C
End temp 390° / 199°C



Start temp 350°F / 176°C
End temp 370° / 188°C



FAQ

Charging & Removeable Battery

- **How long will the MIQRO C's battery last?**

The MIQRO C is powered by a 18350 battery that will last up to 30 minutes. Battery life varies by desired temperature preferences.

- **How do you check MIQRO C's battery life?**

When the device is on, press the Control Button 1 time. The following lights indicate the following:

4 Lights	100% Battery
3 Lights	75% Battery
2 Lights	50% Battery
1 Light	25% Battery

MIQRO C will vibrate when 10% battery life remains.

- **How can I change 18350 lithium-ion battery?**

To remove the battery, open the upper lid and unlatch the battery door compartment. Replace the battery with the 'button' side down and the 'smooth' side up. For securing & best connectivity purposes, the battery latch may require some strength to fully close.

- ❖ Helpful Tip: Use the included Pick-Tool to help simultaneously pull back the latch and close the battery tab at the same time.

- **How does the MIQRO C charge?**

Charge the MIQRO C using the USB Type-C Charging cable that's included in the packaging. You can charge the MIQRO C by connecting the cable to a USB wall adapter or a computer, then insert the cable into the MIQRO C. Once the MIQRO C is connected, the 4 lights will display showing the device is charging. Once the battery is fully charged all four lights will be on to indicate a successful charge.

- ❖ For safe storage, always remove your battery when your MIQRO C is not in use. This will help avoid battery damage and/or corrosion.

- **Can the MIQRO C be used while charging?**

Yes, the MIQRO C is equipped with passthrough charging, so you can use it while charging. In passthrough, the charge speed is reduced to 300mAh to protect the device from overheating. When not in passthrough, the charge speed defaults to 900mAh. With a replaceable battery, you have the option of putting a new battery in while the low battery recharges.

FAQ

Maintenance & Materials

- **How do you clean the MIQRO C?**

To keep the MIQRO C working optimally, we recommend cleaning all ports that encounter vapor regularly. Soak the mouthpiece, 10mm water tool adapter, and vapor path in 70%+ isopropyl alcohol as needed, and finish with a rinse of water. For non-removable ports, use a cotton swab dipped in 70%+ isopropyl alcohol to clean.

Do not submerge the device in liquid of any kind. Do not use abrasive materials to clean the device, oven, or vapor path as damage will occur.

- **What is the mouthpiece made from?**

The top lid is crafted from an FDA-approved antimicrobial polymer. The patented design increases sanitation and feels cooler to the lips. The mouthpiece insert is made from organic, heat-resistant silicone which has been specially cured by our in-house process.

- **What is a "Burn-Off" cycle, and do I need to do one?**

A "Burn-Off" cycle is the process of removing residual odors, chemicals, and any materials left in your oven after cleaning. You should perform a burn-off cycle anytime you want to remove residual odors and loosen cleaning material, especially after thoroughly cleaning your vaporizer.

- **Is the ceramic bowl removable?**

The ceramic bowl is not removable.

FAQ

How-To's

- **How does the MIQRO C connect to water pipes?**

The MIQRO C comes fitted with a flat mouthpiece for discreet, hygienic use. For use with water filtration systems, remove the flat mouthpiece and replace it with the 10MM Water Tool Adapter (silicone).

First, open the top cap of the MIQRO C and remove the flat mouthpiece. Replace it with the 10MM Water Tool Adapter inside of your top cap. Once you have installed your adapter, close the top cap, insert the 10mm adapter into your favorite water tool, and enjoy it!

- **How can I produce dense clouds with the MIQRO C?**

We recommend the following:

1. Pack your ceramic bowl tightly. Remember, you can adjust your Zirconia Pearl to pack a tight bowl with less herb.
2. Increase the temperature of the bowl. The higher the temperature, the more vapor.
3. Draw slowly from the mouthpiece.

- **How do I switch the MIQRO mouthpieces?**

To switch mouthpieces on your MIQRO C follow the steps below:

1. Open the top lid.
2. Push the mouthpiece inward from the top side to detach.
3. Reinstall the new mouthpiece into the top lid and close.

- **How do load/unload the oven bowl?**

To load the MIQRO C oven, turn the devices upside-down and use the loading area to fill with your medium ground dry herb. Pack firmly into the oven until full.

For unloading, use the onboard Pick Tool to stir the contents in your oven. Gently sweep the material from your oven and use a brush tool or cotton swab to sweep any remaining material.

- ❖ When loading and unloading the oven, it is recommended to do so once your material is at a safe temperature. While hot, loading and unloading can cause the risk of burning and/or damage to any brush tools.