



Original and Exclusive Manufacturer:  
Shenzhen Yocan Technology Co.,Ltd  
www.yocan.com  
Sha'er Industrial Area, Shajing Street,  
Baoan District, Shenzhen, China.

Made in China

**SAFETY WARNING & INSTRUCTIONS**  
Please read information carefully before using the product and keep it in a safe place:

**SAFETY WARNING**

1. Do not expose the device to extreme temperatures.
2. Do not charge your battery through a car.
3. Do not over charge or charge unattended.
4. Do not use the device while charging.
5. Do not disassemble the device or change the battery.

Contact your direct seller or Yocan manufacturer for after-sale support:  
www.yocan.com  
service@yocantech.com

- 1 -

**Specification:**

Size: 136.8\*27.5\*13.6mm  
Battery capacity: 650mAh  
Charging type: 5V/0.7A Type-C  
Charging time: 60 minutes  
Resistance: 0.6Ω (XTAL Tip)

The diagram shows the device with dimensions: 27.5mm for the diameter and 136.8mm for the total length.

- 2 -

**Package Content:**

1x Loki Device (XTAL Tip Installed)  
1x Type-C Cable  
1x Instructions Manual

The image shows the Loki device, a Type-C charging cable, and the instructions manual in its packaging.

- 3 -

**How To Use:**

The diagram labels the following parts of the device: Mouthpiece, Battery, Power Button, XTAL Tip, and Cap.

- 4 -

1. Turn on/off: Click the power button 5 times within 2s. The white light will flash 5 times slowly.
2. Install the XTAL tip to the bottom of the battery, solid white lights up for 1s.
3. Adjustable voltage: 3.2V-3.7V-4.2V.  
 ● White = 3.2V   ● Blue = 3.7V   ● Green = 4.2V  
 To change voltage settings, click the power button 3 times continuously to switch from 3.2V to 3.7V to 4.2V.
4. Select mode  
**On-Demand Mode:** Press and hold the button to start vaping, the corresponding color indicator will light up for 15s (15s Auto Cut-Off Protection as white light flashes 5 times then).

- 5 -

**Session Mode:** Press the button 2 times to switch on/off the session mode to vape without pressing, the corresponding color indicator will light up for 15s (15s Auto Cut-Off Protection as white light flashes 5 times then).

5. Use the type-c cable included to charge the battery. The red indicator lights up solidly. When fully charged, the red light turns out.

- 6 -

**Troubleshooting Tips:**

How to fix Yocan Loki light flashing?  
Most of the time, the flashing blink issues resulted in the incorrect connection. Here are some tips to help you fix it.

Please use a Q-tip with Isopropyl alcohol to clean the contact points of the XTAL tip and the battery.  
Try to slide out the contact point of the XTAL tip a little.  
Or install a brand new XTAL tip if you have one.  
If you can't fix this problem, please contact the shop you bought it from.

- 7 -

**Protection:**

Safety Cutoff: If the device is heating continuously for more than 15 seconds, the white light will flash 5 times and stop working.  
No atomizer: White light flashes 3 times.  
Short-circuit: Red light flashes 5 times.  
Low battery: Red light flashes 10 times and stops working.

- 8 -

**Caution:**

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water or any other liquids.  
Do not keep in hot cars or store above the room temperature of 74F.  
Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery.  
Do not use the battery if contacts become exposed to solid or liquid matter. Shorts can result in fire or an explosion of a battery.  
Do not touch coils when hot. Severe burns can result in.  
Do not touch hot material. Severe burns can result in.  
If the device gets too hot in use, please stop using it for a while.  
Not for use with nicotine or other nicotine salt products. Not an ENDS device.

- 9 -

**Disclaimers:**

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product. The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.

- 10 -