



Original and Exclusive Manufacturer:
 Shenzhen Yocan Technology Co.,Ltd
 www.yocan.com
 Sha'er Industrial Area, Shajing Street,
 Baoan District, Shenzhen, China.

Made in China

SAFETY WARNING & INSTRUCTIONS
 Please read information carefully before using the product and keep it in a safe place:

SAFETY WARNING

1. Do not expose the device to extreme temperatures.
2. Do not charge your battery through a car.
3. Do not over charge or charge unattended.
4. Do not use the device while charging.
5. Do not disassemble the device or change the battery.

Contact your direct seller or Yocan manufacturer for after-sale support:
 www.yocan.com
 service@yocantech.com

Specification:

Battery Size: 11.2*79.2mm
 Battery Capacity: 350mAh
 Voltage Range: 3.4V, 3.8V, 4.2V
 Pre-Heat Type: 1.8V/10s Pre-Heating
 Cartridge Size: 11.2*49mm
 Cartridge Capacity: 1.0ml
 Coil Type: Wickless Ceramic Coil
 Coil Resistance: 1.4ohm
 Charging Type: 5V/0.4A Micro-USB
 Charging Time: 50 Minutes
 Standby Current: <10uA

Safety Protection: Low Battery Protection, No Load Protection, Loading Detection, Short-Circuit Protection.

Package Content:

1x Stix 2.0 Battery
 1x Full Ceramic Cartridge

How To Use:

1. Advanced mode: this mode contains Adjustable Voltage & Pre-heat & Auto-draw functions.
2. Regular mode: Auto-draw Only.
3. Turn on/off the advanced mode: Slap the battery 5 times within 2s. The trio green light will flash 5 times when turning on this mode and the trio red light will flash 5 times when turning off this mode.
4. Pre-heat function: In the advanced mode state, tap the battery twice with your finger and the trio green lights will stay on 10 seconds at 1.8V. Then tap twice again to switch off the preheat function.
 Note: If you use thicker oils, please preheat thoroughly to avoid clogged problems.
5. Auto draw function: Inhale directly.

6. Adjustable voltage: 3.4V - 3.8V - 4.2V.

To change voltage settings, slap the battery 3 times continuously to switch from 3.4V to 3.8V to 4.2V.

7. Low-battery Reminder: when the battery is under 3.2V, the red light will flash 10 times and the battery and atomizer will not work. Then use a USB charger to charge it up.
8. Other atomizer options: the battery supports other >0.8 Ohm atomizers.
9. When you want to tap/slap the device, please use the bottom of the device to tap the palm.

Troubleshooting Tips:

1. If you cannot auto draw successfully, please check whether you have screwed the atomizer in the battery tightly or not.
2. If the battery reminds no atomizer but you have loaded an atomizer, please slap 5 times to turn off the advanced mode and then use Q-tip with isopropyl alcohol to clean the 510 thread, then try again.
3. To avoid damage to the central tube of the atomizer, please use a syringe with a thinner needle to fill oils into the atomizer.
4. To avoid wrong operations, please slap 5 times to turn off the advanced mode if you have set the desired voltage but you want to use later or do not want to use currently.
5. If there are clogged problems happened in the top part of the mouthpiece,

please use Q-tip with isopropyl alcohol to clean it up regularly.

6. If the tapping/slapping function is not sensitive, you can tap the bottom of the device (i.e., the charging port) then it will be better, or you may charge up the device.

Protection:

Safety Cutoff: If the device is heating continuously for more than 10 seconds, the green light will flash 8 times and stop working.
 No atomizer: Green and red lights flash 1 time in turn.
 Short-circuit: Green and red lights flash 1 time in turn.
 Low battery: Red light flashes 10 times and stops working.
 Automatic standby protection: the device will be switched into the regular mode automatically in 30 minutes.

Caution:

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water, or any other liquids.
 Do not keep in hot cars or store above the room temperature of 74F.
 Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery.
 Do not use the battery if contacts become exposed to solid or liquid matter. Shorts can result in fire or an explosion of a battery.
 Do not touch coils when hot. Severe burns can result in.
 Do not touch hot material. Severe burns can result in.
 If the device gets too hot in use, please stop using it for a while.
 Not for use with nicotine or other nicotine salt products. Not an ENDS device.

Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product. The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.