

IMPORTANT SAFETY WARNINGS:

Do not expose to extreme temperature or direct sunlight.
Do not drop the Pulsar® Mobi or accessories.
Do not drop or submerge in any liquid.
Do not modify the electronics in any way.
Only charge using Pulsar brand chargers and Pulsar brand accessories.
Do not sell or provide to minors. Pulsar Mobi is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, or personal injury.

WARRANTY:

Pulsar Mobi is guaranteed from manufacturer defects or malfunction from the original date of purchase for a period of 6 months. This limited warranty protects against manufacturer defects under normal use and does not apply to normal wear and tear, improper use, and accidental damage from dropping or submerging in liquid, improper cleaning, neglect, or any other damage that is not a result of defective materials or workmanship. If your Pulsar Mobi qualifies for servicing, we will repair or replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Pulsar Mobi will void the warranty. Warranty is non-transferable. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

PulsarVaporizers.com
Manufactured By Pulsar®
Asheville, NC

Designed in USA • Made in China
PU-0306-21



PULSAR®

Mobi

THICK OIL
VAPORIZER

#ENJOYHIGHERCULTURE

PulsarVaporizers.com

User Manual

SPECIFICATIONS

Size: 23.5x18.5x71mm
Battery Capacity: 650mAh
Wattage: 15W
Voltage: 2.8V, 3.2V, 3.7V, 4.2V
Preheat: 2 Clicks with 2.2V for 17s
Charger: USB Charger

HOW TO

Power On/Off - Press the power button 5 times rapidly to power on/off.

Preheat Function - Click power button 2 times to preheat.

Changing Voltage - Click the Shift Button 1 time, to change vv. 2.8V with one light, 3.2V with two lights, 3.7V with three lights, 4.2V with four lights.

Charging - 1 light 25% charged, 2 lights 50% charged, 3 lights 75% charged, 4 lights is fully charged.

POWER OFF unit prior to charging.
REMOVE CARTRIDGE prior to charging.

FEATURES

- Pocket friendly design.
- Extremely stealthy.
- Preheat function & 4 voltage settings.
- Independent Voltage Shift Button.
- Fits most cartridges on the market.

Pulsar® Mobi Overview

